

ver. 1.0




Bungees for iX3M

ATTENTION: Risk of iX3M loss

Always ensure that bungees are well fixed. If they are worn out, replace them.

Remove the elastic bands from your iX3M



1

Insert the bungee inside the loop from the outside to the inside (a certain manual skill is necessary)



Insert the bungee again from the outside excluding one loop as shown in the picture.



3

Repeat the operation and insert the bungee in the inside of the two loops created.



Tighten the bungee carefully and check that the two pins grab the bungee well.



Adapt the measure to one's own arm and repeat the operation in the other loop



Repeat also on the other side.



Once the correct measure of the two bungees has been found, cut the exceeding part and burn the two ends.

